Griplok[®] Tube Fittings

Griplok[®] two-ferrule tube fittings provide leak-tight installation when intermixed with Hoke[®] Gyrolok[®] fittings, provided they are used in accordance with SSP Fittings' published installation and service recommendations.

To provide a reliable, leak-proof connection in instrumentation and process tubing systems, Griplok tube fittings consist of four precisionmachined components: **OBody**, **OFront Ferrule**, **ORear Ferrule**, and **ONLE**.

Lifetime Warranty

Griplok tube fittings are covered by a lifetime limited warranty. Visit **www.mySSP.com** for details.



8250 Boyle Parkway Twinsburg, OH 44087 U.S.A. P: 1.330.425.4250





Griplok Tube Fittings

INSTALLATION INSTRUCTIONS

- 1. Remove the tube fitting from protective bag.
- 2. Fully insert the tube into the Griplok tube fitting body, then hand tighten the Griplok nut. See Figure #1
- 3. While holding the fitting body stable with a back-up wrench, scribe the nut for a reference point and wrench-tighten 1 and 1/4 turns. See Figures 2 and 3.

