

## How to Order - Bleed Valves (BV Series)

1 Locate the Basic Part Number from the Part Number and Dimensions table below.

2 Add the designators for options

**NOTE:** The Part Number and Dimensions Tables contain the most popular part numbers. Valves can be configured with different end connection types and sizes. For valves with other requirements contact your local SSP Distributor or SSP Customer Service.





( A )	BASIC PART NUMBER	
•	BV2PM	1/8 in. Male NPT
	BV4PM	1/4 in. Male NPT
	BV6PM	3/8 in. Male NPT
	BV8PM	1/2 in. Male NPT
	BV4PMST	1/4 in., 7 16-20 Male SA
	BV8PMST	1/2 in., 3/4-16 Male SAE
	BV4PMRT	1/4 in. Male ISO
	<b>BV8PMRT</b>	1/2 in. Male ISO



\* Contact SSP Customer Service for availability.



OPTIONSNVTNo VentTube StubBlankC3Barbed Vent TubeTBH316 SS Bar Handle