

To order Metering valves, follow the steps below.

- 1 Add the Angle Pattern Designator. Example **A**500-316
- 2 Add the Basic Ordering Number. Example **A**500-316
- 3 Add the Material Designator (Optional). Example: A500-**316**

(basic part number)

A **B** - **C**
A **500** **316**



A **ANGLE PATTERN**
Blank *Straight Pattern*
 (Standard)

A *Angle Pattern*

B **BASIC ORDERING NUMBER**
See Catalog for Basic
Ordering Number

C **MATERIAL**
Blank *Brass*
316 *Stainless Steel*