


## How to Order - Metering Valves

### Ordering Information

To order, add the Material Designator as a suffix and the Angle Pattern Designator as a prefix to the basic ordering number found in the tables on pages 22-23.

### Part Number Configuration



### Material Designators

**Brass** - No suffix required

**Stainless Steel** -316

### Angle Pattern Designator

**Straight Pattern** - No prefix required (Straight Pattern standard)

**Angle Pattern** - A (prefix to basic ordering number)